

Velcro strip should be positioned 1 cm above the corner of the pocket and 1 cm from the edge of the arm. Note: pocket is on an angle, name tape should be sewn on horizontally, NOT in line with the pocket.

1 cm



H

1 cm



NAME TAPE GOES ON THE RIGHT SIDE OF THE JACKET.